

S H E R L E



W A G N E R
INTERNATIONAL

INSTALLATION GUIDE

SHOWERHEADS & BODY SPRAYS & RAIN BARS

		<ol style="list-style-type: none"> 1. Apply Teflon tape to both ends of shower arm (1). 2. Insert wall end of shower arm (1) into shower arm escutcheon (2). 3. Screw wall end of shower arm (1) into shower riser connection (3) inside wall. 4. Thread shower head (4) onto shower arm (1).
--	--	---

Installation tools that may be needed:

