




Hand Shower Unit

# **Operation & Maintenance Manual**




#### **Dimensions**



Measurements			
Α	3-1/8", 79 mm		
В	Male 1/2-14 NPT fitting must		
	be recessed 1/4" (6 mm)		
	from finished wall		
С	(2x) Hole Size		
	Dry wall: Ø 3/16", 5 mm		
	Stud: Ø 1/8", 3 mm		
D	28-5/16", 719 mm		

Note: Dimensions subject to change without notice.

# Parts Breakdown



Replacement Parts				
Item	Description	Part Number		
Α	Hand Shower	402W*		
В				
С	Slide Bar	EF-02284*		
D				
Е	Wall Elbow	EF-105*		
F	Vacuum Breaker (optional)	EF-109*		
G	60" Hose	EF-02976		

Note: Append modification -STN to part number for Satin Nickel finish.


Tools Required for Installation				
Adjustable Wrench				
Allen Wrench: 3 mm				
Phillips Head Screwdriver				
Plumber Tape				
Power Drill				
Silicone				

#### Notes:

- 1) Apply a bead of silicone around the perimeter of all shower trim installed flush to the finished wall (less mounting plates and brackets). Leave opening on bottom of escutcheons for weep hole.
- 2) Apply plumber tape to all threaded connections.


## Installation

1a) Dry Wall Option: Remove upper and lower caps (B) from slide bar brackets. Place slide bar (D) into desired position. Using brackets as a guide, carefully drill 3/16" holes into wall. Remove slide bar and install anchors.




**Notes:** Make sure that slide bar holes and bracket holes are aligned before drilling. Before drilling bottom hole, make sure slide bar is plumb.

1b) Stud Option: Remove upper and lower caps (B) from slide bar brackets. Place slide bar (D) into desired position. Using brackets as a guide, carefully drill 1/8" pilot holes into stud.




**Notes:** Make sure that slide bar holes and bracket holes are aligned before drilling. Before drilling bottom hole, make sure slide bar is plumb.


 With slide bar (D) in position, secure to wall using screws (C).
 Replace upper and lower caps (B) onto slide bar brackets.



## Installation

 Install wall elbow (E) to stub out pipe. Tighten set screw to secure. 4) Attach large end of hose (G) to hand shower wand (A).
Attach small end of hose (G) to wall elbow (E). Turn clockwise to tighten.





# **Troubleshooting Chart**

Troubleshooting Chart						
Finish is spotting.	Elements in water supply may cause water staining on finish.	Clean finished trim area with a soft cloth using mild soap and water or a non-abrasive cleaner and then quickly rinse with water.				

**WARNING:** This product can expose you to chemicals including lead, which is known to the state of California to cause cancer, birth defects, or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.