



ш



2 ASSEMBLE FLOOR ESCUTCHEONS AND RISER PIPING

- Apply sealing tape or sealant to threads of RISER PIPES (1).
- Slide FLOOR ESCUTCHEONS (2) onto RISER PIPES (1).
- With wrenches connect the STUD ADAPTERS (3) to RISER PIPES (1).
- Tighten MOUNTING STUDS (4) to RISER PIPES (1) with HEX WRENCH (5) supplied.



3 INSTALL RISER SUPPLY PIPING

- Install ESCUTCHEON SEALS (1) into groove in escutcheon base.
- Slide BRASS WASHERS (2) onto RISER PIPES (3).
- Install RISER SUPPLY PIPES (3) into mounting holes in floor. From underside of floor install BRASS WASHERS (2) and LOCK NUTS (4) onto RISER SUPPLY PIPES (3). Do not tighten LOCK NUTS (4) fully.

